

- 1.4 ASIC: Less power consumption, chip area, higher throughput, more costly design process, longer design time, less flexibility,

Standard DSPs: Flexible, design errors can easily be corrected, easy to update as better DSPs becomes available, well-known design process, high power consumption, higher unit cost, low throughput,